
INSTRUCTIONS FOR USE OF THE LOCKING DEVICE SUPPLIED WITH YOUR NEW RUGER® FIREARM

Beginning in 2003, all newly manufactured Ruger[®] firearms are being shipped from the factory with a new key-operated locking device. This is a California-approved firearms safety device that meets the requirements of California Penal Code Section 12088 and the regulations issued thereunder. This new locking device is designed to help you meet your responsibility to keep your firearm stored in a safe condition. This device does <u>not</u> relieve the firearms owner or handler from the obligation of always paying strict attention to gun safety rules.



WARNING – USE OF LOCKING DEVICES



- Read the owner's manual supplied with your firearm before attempting to install your locking device. (Manuals are available free upon request from Sturm, Ruger.)
- Always keep your firearm pointed in a safe direction, including when you are installing or removing your locking device.
- Always verify that your firearm is completely <u>unloaded</u> before installing your locking device.
- Do <u>not</u> install locking devices in the trigger guard; always keep your fingers, clamp and locking device outside the trigger guard during device installation and removal.
- Store firearms, ammunition and keys separately and securely, away from children and careless adults; do <u>not</u> store your firearm with the keys in the locking device.
- Do not attempt to work the action of your firearm with the locking device in place; this may damage your firearm.
- While locking devices are an important aid to security measures, they are not a
 substitute for safe firearm handling and proper storage. Remember that any
 mechanical device can be bypassed with enough time, knowledge, determination
 and equipment.


LOCKING DEVICES MUST BE USED SAFELY AND RESPONSIBLY

<u>Use the Correct Lock:</u> While the basic locking device is substantially similar for all Ruger[®] firearms, due to the different shapes of the many Ruger[®] firearms, some firearms require the use of a clamp (black metal bracket to which the lock is applied). The 1 1/2" lock (without the vinyl coating) is for use with the Ruger[®] No. 1 Rifles <u>only</u> which do not require a clamp. It is very important that you use the correct locking device and clamp when locking your Ruger[®] firearm!

To Install the Factory-Supplied Locking Device on Your Ruger® Firearm:

- 1. Keep the muzzle pointed in a safe direction and your fingers outside the trigger guard at all times!
- 2. Be sure the firearm is completely unloaded and contains no cartridges or cartridge casings!
 - —— See Other Side For Additional Instructions & Important Safety Warnings ——

- 3. Open the action completely. Keep the action open during installation of the locking device.
- 4. Apply the lock by placing the shackle of the lock into your Ruger® No. 1 Rifle as shown in Figure 1.
- 5. Close the lock by pressing the shackle into the body of the lock (the part that receives the key) as tightly together as possible. The lock has bumpers and the shackle is coated with a non-marring material that will not harm the metal finish of your firearm; be careful not to dent or scratch wooden stocks or grips.
- 6. Once the lock is securely closed, remove the key and pull firmly on the lock to test the connection and be sure it is locked. Do not leave or store your firearm with the key in the lock! Store your locked unloaded firearm and the key in secure, separate locations, away from ammunition, children, or unauthorized adults.



For Ruger® No. 1 Rifles Only

Remember that secure and safe firearms storage is an important responsibility that comes with your ownership of firearms. You may obtain a list of locking devices available for purchase at your local firearms retailer that have been tested and certified by California-approved laboratories for use with other firearms by contacting the California Department of Justice at (916) 322-3360 or visit their website at http://caag.state.ca.us. If you have any questions about what are legally appropriate locking devices in your state, or about local laws concerning safe storage requirements for firearms and ammunition, please contact your local police.